


ASURA

Hinged Door with Inline & Side Panel

PRODUCT CODES:

AUHDILPSC1000	AUSPHDC800
AUHDILPSC1200	AUSPHDC900
AUHDILPSC1400	AUSPHDB800
AUHDILPSC1700	AUSPHDB900
AUHDILPSB1000	AUSPHDF800
AUHDILPSB1200	AUSPHDF900
AUHDILPSB1400	AUSPHDV800
AUHDILPSB1700	AUSPHDV900
AUHDILPSF1000	AUSPHDBZ800
AUHDILPSF1200	AUSPHDBZ900
AUHDILPSF1400	AUSPHDT800
AUHDILPSF1700	AUSPHDT900
AUHDILPSV1000	
AUHDILPSV1200	
AUHDILPSV1400	
AUHDILPSV1700	
AUHDILPSBZ1000	
AUHDILPSBZ1200	
AUHDILPSBZ1400	
AUHDILPSBZ1700	
AUHDILPST1000	
AUHDILPST1200	
AUHDILPST1400	
AUHDILPST1700	



AUSLEEKx



AUFLUTEDx



AUHAMMEREDx

Optional handle (not supplied with shower doors)

1. Pre-Installation Checklist

☑ Before You Begin:

- Ensure all tiling/grouting is complete.
- Shower tray **must be level and sealed** to tiles.
- Verify door dimensions match your space (see Section 3).
- Check for hidden pipes/cables before drilling.

⚠ Safety Notes:

- **Two people required** for installation (glass is heavy!).
- Wear gloves when handling glass edges.

2. Unpacking & Components

Confirm all parts are present:

- Please refer to all components included on following page titled “COMPONENTS”

Missing/Damaged Parts?

Contact Crosswater immediately: ☎0345 873 8840.

3. Step-by-Step Installation

A. Frame Assembly

1) Mark Drill Points:

- Use a spirit level to mark vertical lines for wall profiles.
- Drill 6mm holes at marked points; insert wall plugs.

2) Attach Wall Profiles:

- Secure profiles with ST4x50mm screws (×8 total).
- Cover ends with profile caps if any.

B. Door Installation

3) Hang the Door:

- Following the instruction to assemble the door, ensure door is fully secured.
- Make necessary adjustment if door doesn't close smoothly.

4) Apply Seals:

- Install necessary seals provided on door and side panel if any.

C. Final Checks

5) Level & Secure:


- Confirm door is level; tighten all screws.
- Let silicone cure for 24 hours before use.

4. Care & Maintenance


- **Cleaning:** Use only **pH-neutral soapy water** (pH 6.8–7.2).
- **Avoid:** Abrasives, solvents, or acidic cleaners.

Ensure seals are flush to prevent leaks.


ORIENTATION



Tools Required (not supplied):

Spirit Level		Torque Screw Driver	
Pencil		Snips	
Drill		6mm Drill Bit	
Silicone		Measuring Tape	
Knife			


COMPONENTS




1 Screw M4*12 x1	2 Wall Profile Cap x1	3 Wall Profile x1	23 Side Panel Seal x1
4 Fixed Panel x1	5 Wall Plug x8	6 Screw ST4*50 x8	24 Side Panel x1
7 Fixed Panel Seal x1	8 Moving Panel x1	9 Soft Close Hinge x2	25 Wedge Seal x1
10 Door Bottom Seal x1	11 Bottom Connector LH RH x1	12 Bottom Profile x1	26 Side Panel Wall Profile x1
13 Bottom Profile Cap x1	14 Profile Seal x1	15 Seal Profile x1	27 Screw ST4*50 x4
16 Optional Handle (Not Supplied With Shower Door) x1	17 Seal Profile Cap x1	18 Bracing Bar x1	28 Wall Plug x4
19 Moving Panel Tool x2	20 Fixed Panel Gasket 1mm 2mm x1	21 Screw Drilling Hole Positioning Tool x1	29 Side Panel Top Cap x1
22 Allen Key 2.5 mm 4mm x1	33 Allen Key 2.5 mm 4mm x1	32 Wedge Gasket Tool x1	30 Glass Clamp x1
			31 Connector LH RH x1

INSTALLATION

1




2




INSTALLATION

3





4




INSTALLATION

5



Ensure the fixed panel is level.
Use the gasket as shown in the
diagrams if needed.


6




Product	L(mm)
Asura Hinged Door with inline 1000	628
Asura Hinged Door with inline 1200	678
Asura Hinged Door with inline 1400	678
Asura Hinged Door with inline 1700	678

INSTALLATION

7









8





INSTALLATION

9




10




INSTALLATION

11










12








INSTALLATION

13




14




INSTALLATION

15




16



INSTALLATION


3



Product	X(mm)
Asura Hinged Door with inline 1000	973-988
Asura Hinged Door with inline 1200	1173-1188
Asura Hinged Door with inline 1400	1373-1388
Asura Hinged Door with inline 1700	1673-1688


Product	Y(mm)
Asura 800mm Side Panel for Soft Close Hinged Door	760-775
Asura 900mm Side Panel for Soft Close Hinged Door	860-875

100%





Y


X





4












13


INSTALLATION

5



Ensure the fixed panel is level.
Use the gasket as shown in the
diagrams if needed.




6










Product	L(mm)
Asura Hinged Door with inline 1000	615
Asura Hinged Door with inline 1200	665
Asura Hinged Door with inline 1400	665
Asura Hinged Door with inline 1700	665

INSTALLATION

7




8




INSTALLATION

9




10




INSTALLATION

11




12




INSTALLATION

13




14




INSTALLATION

15



16



INSTALLATION

17

