
# Installation Instruction

## Single Handle Kitchen Faucet

# Before Your Installation

Check to make sure you have the following parts indicated below:



# Tools You Will Need



Adjustable wrench




Spanner for aerator (supplied)



Spanner for body (supplied)

# Replacement Parts


Keep this manual for ordering replacement parts.



### NO NAME


- 1. Aerator
- 2. Spout
- 3. Anti-friction gasket
- 4. Plastic lock ring
- 5. O-ring
- 6. Plastic lock ring
- 7. Screw
- 8. Faucet body
- 9. Cartridge
- 10. Screw
- 11. Lock nut
- 12. Cartridge holder
- 13. Handle body
- 14. Screw
- 15. Pedestal
- 16. O-ring
- 17. Rubber gasket
- 18. Stainless steel gasket
- 19. Lock screw
- 20. Lock nut
- 21. Hose


# Product Dimension Drawing




# Faucet Installation Procedures

Step ①







Step ②




Step ③




Step ④





# Step 9



### Notice:

Please removing all of the sand, silt and other things from the water hose before assembling, to avoid blocking the faucet and effecting water rate. Please use the special tools to disassemble it and wash with pneumatic equipment, if the faucet blocked.