
## crosswater<sup>X</sup>



Dial Shower head

FH225C+

# ×\_najewsono

guarantee may be considered invalid. Level 3. Should the installation be completed by a non-qualified person then the Vocational Qualification) or SNVQ (Scottish National Vocational Qualification) This product should only be fitted by a qualified plumber to NVQ (National

area please visit the Institute of Plumbers website - www.iphe.org.uk. tials can be required. For further information or to find a qualified installer in your For a claim made under our warranty written certification of your installers creden-

### THE QUALIFICATIONS

ing plumber. Colleges should help students find a work placement, although many classroom/purpose built training facility and work based experience with a workland). These qualifications are made up of theory and practical work in the tion (MVQ) route (Scottish National Vocational Qualification - SNVQ - in Scot-At present, to be a plumber you need to follow the National Vocational Qualifica-

domestic, commercial and industrial plumbing along with aspects such as gas - if plumbing to a satisfactory level. Level 3 is more comprehensive and deals with you the foundation you need for a career in plumbing and teach you domestic hold S/NVQ Level 2 as basic with Level 3 as the preferred level. Level 2 will give The S/NVQ qualification works in levels. All recently qualified plumbers should students organise it themselves.

Heating Engineering, and the industry as a whole recommends that all plumbers your own business, this is the level to reach. The Institute of Plumbing and you want to one day set up

in membership with the Institute for five years as a Member MIPHE) gain Engithey have the relevant experience as well. Those with S/NVQ Level 3 can (once Certificate, which only those attaining Level 3 or equivalent can reach as long as Reaching Level 3 has other advantages. The Institute runs a Master Plumber reach a minimum of Level 3.

neering Technician EngTech status with the Engineering Council (UK).

General Installation Requirements Please read these instructions carefully and keep in a safe place for future reference.

as damage resulting from the installation process, incorrect maintenance or misuse and as a result not be claimable under

The installation must comply with regulations of the Local Water Authority as contained in their bylaws.

INTRODUCTION

### Standard specifications

- 3. Maximum hot water temperature: 2. Maximum test pressure: ... 1. Recommended working pressure: ...
- if the above mentioned conditions (see points 1,2,3,4) are not observed, the product may not correctly work or not work at 5. Warning:
- On receipt of this product the chrome finish must be checked for blemishes. Defects notified after fitting may be regarded

4. We recommend installing filters to this product.

Approvals the warranty.

WARNING

All products are manufactured using materials tested and approved under the Water Bylaws Scheme and comply with


requirements of British Standard 5412:1996 where applicable.




- Installation Performed By Qualified Personnel Only ! Clean Carefully The Water Pipes Before Installing The Tap.



The manufacturer reserves the right to make technical modifications without prior notice. Or visit our web-site at www.crosswater.co.uk For any further information please contact Crosswater on: 0845 873 8840





Note: all dimensions in millimetres

4


### INSTALLATION



Remember to turn off the mains water supply before connecting to any existing pipe work. Flush the piping with plenty of water prior to installation.

### Installation Instructions:

- 1. Loosely assemble the product as per the exploded drawing, note some parts may be supplied pre assembled. Do not disassemble any assemblies unless required to complete installation.
- 2. Attach any plumbing inlet connections as shown.
- 3. Attach any mounting fixings as indicated; secure the product firmly to the mounting surface.
- 4. Where the product includes a shower outlet refer to the separate instructions supplied.



- A Shower arm / Wall outlet
- **(E)** Lower seal
- B Mesh filter
- F Grub screw
- © Locking snodo
- **G** Allen key (size 1.5, 2.5 dependant on model)
- Showerhead

The chrome plate we use on our showerhead is very durable, nevertheless care should be taken when cleaning them. They should be cleaned only with warm soapy water followed by rinsing with clean water and drying with a soft cloth. lowed by rinsing with clean water and drying with a soft cloth. All finishes are vulnerable to acid attack and some strong substances such as household cleaners, disinfectants, denture cleaners, hair dyes, wine making and photographic chemicals can cause the surface to go black or peel.

6

5